



SENTRISENSE

Making the grid smarter



Installation guide

Guía de instalación

Installation in 4 simple steps



1 Connecting the antenna

The device includes an antenna, which is required to connect the device to the internet and send data to the web platform.

Step 1: Place the antenna in the connector.

Step 2: Turn the antenna clockwise.



2 Switching-ON

Step 1: Press the power button.


Step 2: The device will turn ON the red LED, and it will begin to self-configure for about 3 minutes.

Step 3: Once the configuration has finished and first data is sent, the red LED will blink and a beep will be heard. If several beeps are heard, please refer to the user manual.



3 Mounting

Pull the rings of the mounting clamp until they lock, place the device on the high voltage line and close the clamp. For this process use the corresponding tool.



4 Dashboard

On a computer or mobile device go to **dashboard.lessindustries.com** and log in with your user and password (if you don't have one create your user first). Then search for the **LESS_ID** provided in the label placed on the device's side.



Instalación en 4 sencillos pasos



1 Conectando la antena

El dispositivo incluye una antena, que es necesaria para conectar el dispositivo a Internet y enviar datos a la plataforma web.

Paso 1: Coloque la antena en el conector.

Paso 2: Gire la antena en el sentido de las agujas del reloj.



2 Encendido

Paso 1: Presiona el boton de encendido.


Paso 2: El dispositivo encenderá el LED rojo y comenzará a autoconfigurarse durante aproximadamente 3 minutos.

Paso 3: Una vez que la configuración haya finalizado y se envíen los primeros datos, el LED rojo parpadeará y se escuchará un pitido. Si se escuchan varios pitidos, consulte el manual del usuario.



3 Montaje

Tire de los anillos del clamp de montaje hasta que se bloqueen, coloque el dispositivo en la línea de alto voltaje y cierre el clamp. Para este proceso utilice la herramienta correspondiente.



4 Dashboard

En su computadora o dispositivo móvil, vaya a **dashboard.lessindustries.com** e inicie sesión con su usuario y contraseña (si no tiene una, cree su usuario primero). Luego busque el **LESS_ID** provisto en la etiqueta colocada en el costado del dispositivo.

